



# P100 Series

## INDUCTIVE PROXIMITY SENSOR



EN - FR - CN - RU



INSTALLATION INSTRUCTIONS



# OPERATION MANUAL




Part No's. P1003V34AI/x/B4

[www.go4b.com](http://www.go4b.com)



# TABLE OF CONTENTS

CUSTOMER SAFETY RESPONSIBILITIES	Page 4 - 5
PRODUCT OVERVIEW	Page 6
SPECIFICATIONS	Page 6
APPROVALS	Page 7
DIMENSIONS	Page 8
INSTALLATION	Page 8 - 9
STANDARD WIRING DIAGRAM	Page 10 - 11
TESTING & COMMISSIONING	Page 12
TROUBLESHOOTING GUIDE	Page 13
PRODUCT WARRANTY	Page 14

 	 <b>WARNING</b>  <b>Rotating parts can crush, cut and entangle.</b> <b>Do NOT operate with guard removed.</b> <b>Lockout power before removing guard or servicing.</b>
--	---

Dear 4B Customer:

Congratulations on your purchase. 4B appreciates your business and is pleased you have chosen our products to meet your needs.

Please read in its entirety and understand the literature accompanying the product before you place the product into service. Please read the safety precautions carefully before operating the product. With each product you purchase from 4B, there are some basic but important safety considerations you must follow to be sure your purchase is permitted to perform its design function and operate properly and safely, giving you many years of reliable service. Please read and understand the Customer Safety Responsibilities listed below. Failure to follow this safety directive and the Operation Manuals and other material furnished or referenced, may result in serious injury or death.

### **SAFETY NOTICE TO OUR CUSTOMERS**

- A. In order to maximize efficiency and safety, selecting the right equipment for each operation is vital. The proper installation of the equipment, and regular maintenance and inspection is equally important in continuing the proper operation and safety of the product. The proper installation and maintenance of all our products is the responsibility of the user unless you have asked 4B to perform these tasks.
- B. All installation and wiring must be in accordance with Local and National Electrical Codes and other standards applicable to your industry. The installation of the wiring should be undertaken by an experienced and qualified professional electrician. Failure to correctly wire any product and/or machinery can result in the product or machine failing to operate as intended, and can defeat its design function.
- C. Periodic inspection by a qualified person will help assure your 4B product is performing properly. 4B recommends a documented inspection at least annually and more frequently under high use conditions.
- D. Please see the last page of this manual for all warranty information regarding this product.

### **CUSTOMER SAFETY RESPONSIBILITIES**

#### **1. READ ALL LITERATURE PROVIDED WITH YOUR PRODUCT**

Please read all user, instruction and safety manuals to ensure that you understand your product operation and are able to safely and effectively use this product.

#### **2. YOU BEST UNDERSTAND YOUR NEEDS**

Every customer and operation is unique, and only you best know the specific needs and capabilities of your operation. Please go to [www.go4b.com](http://www.go4b.com) or call the 24-hour hotline at +1-309-698-5611 for assistance with any questions about the performance of products purchased from 4B. 4B is happy to discuss product performance with you at any time.

### **3. SELECT A QUALIFIED AND COMPETENT INSTALLER**

Correct installation of the product is important for safety and performance. If you have not asked 4B to perform the installation of the unit on your behalf, it is critical for the safety of your operation and those who may perform work on your operation that you select a qualified and competent electrical installer to undertake the installation. The product must be installed properly to perform its designed functions. The installer should be qualified, trained, and competent to perform the installation in accordance with local and national electrical codes, all relevant regulations, as well as any of your own standards and preventive maintenance requirements, and other product installation information supplied with the product. You should be prepared to provide the installer with all necessary installation information to assist in the installation.

### **4. ESTABLISH AND FOLLOW A REGULAR MAINTENANCE AND INSPECTION SCHEDULE FOR YOUR 4B PRODUCTS**

You should develop a proper maintenance and inspection program to confirm that your system is in good working order at all times. You will be in the best position to determine the appropriate frequency for inspection. Many different factors known to the user will assist you in deciding the frequency of inspection. These factors may include but are not limited to weather conditions; construction work at the facility; hours of operation; animal or insect infestation; and the real-world experience of knowing how your employees perform their jobs. The personnel or person you select to install, operate, maintain, inspect or perform any work whatsoever, should be trained and qualified to perform these important functions. Complete and accurate records of the maintenance and inspection process should be created and retained by you at all times.

### **5. RETAIN AND REFER TO THE OPERATION MANUAL FOR 4B'S SUGGESTED MAINTENANCE AND INSPECTION RECOMMENDATIONS**

As all operations are different, please understand that your specific operation may require additional adjustments in the maintenance and inspection process essential to permit the monitoring device to perform its intended function. Retain the Operation Manual and other important maintenance and service documents provided by 4B and have them readily available for people servicing your 4B equipment. Should you have any questions, please call go to [www.go4b.com](http://www.go4b.com) or call the 24-hour hotline at +1-309-698-5611.

### **6. SERVICE REQUEST**

If you have questions or comments about the operation of your unit or require the unit to be serviced please contact the 4B location who supplied the product or send your request go to [www.go4b.com](http://www.go4b.com) or call the 24-hour hotline at +1-309-698-5611. Please have available product part numbers, serial numbers, and approximate date of installation. In order to assist you, after the product has been placed into service, complete the online product registration section which is accessed via our website [www.go4b.com](http://www.go4b.com).

## WARNING

- Rotating machinery can cause serious injury or death
- Always lockout and tagout the machine prior to installation

## PRODUCT OVERVIEW

The P100 is an inductive sensor designed to detect shaft speed, shaft position, gate position, or object presence. No contact is made between the sensor and the object being monitored.

Maximum range of ferrous targets is 6 mm (15/64") and for non-ferrous targets is 5 mm (13/64"), assuming a 20 mm (3/4") diameter target. Smaller targets may be used but operating distances will be reduced. Three different sensor outputs are available.










P1003V34AI/x/B4 has an isolated transistor and the output is determined by the orientation of the positive and negative supply connections (page 10).

All units are fully encapsulated and come with a prewired cable. A blue LED indicates a target is detected.


## SPECIFICATIONS

Supply Voltage:	10-30VDC
Supply Fusing:	Supply to be fused at 500mA maximum. Note: fuse must be 1500A capable. 1 fuse per sensor <b><u>MUST</u></b> be used.
Switching Capacity:	Opto-isolated transistor, 30VDC, 100mA max
Ambient Temperature:	5°F (-15°C) to +122°F (+50°C)
Output State:	See page 10
Sensing Range:	6 mm (15/64") maximum on ferrous metal at 77°F (25°C) 5 mm (13/64") maximum on non-ferrous metal at 77°F (25°C)
Input Pulse Range:	10 to 3,600 pulses per minute (PPM) maximum
Enclosure:	GRILON POLYAMIDE - ISO threaded 18 mm by 1.0 mm pitch
Relative Humidity:	90% RH
LED Indicators:	Blue - Target Sensed
Connections:	4 wire  <b>NOTE:</b> cable length designated by /xx at the end of the part number; e.g. P1003V34AI/5/B4 would have a 5m cable.
Protection:	IP66

# APPROVALS

ATEX	Baseefa14ATEX0115X  II 2G Ex mb IIC T5 Gb  II 2D Ex mb IIIC T100°C Db Tamb - 15°C to +50°C  I M2 Ex mb I Mb
IECEX	IECEXBAS14.0061X Ex mb IIC T5 Gb Ex mb IIIC t100°C Db I M2 Ex mb I Mb Tamb - 15°C to +50°C
CCC	CQC - 2023012315595565 Ex mb IIIC T100°C Db IP66 -15°C≤Tamb≤+50°C
EACEx	RU C-GB.Aд07.B.02814/20  PB Ex mb I Mb X  1 Ex mb IIC T5 Gb X  Ex mb IIIC T100°C Db X OT -15 до +50 IP66
UKEx	BAS21UKEX0316X  II 2G Ex mb IIC T5 Gb  II 2D Ex mb IIIC T100°C Db Tamb - 15°C to +50°C  I M2 Ex mb I Mb
CSA (North America)	Class II, Division 1 Groups E, F and G

## DIMENSIONS



**NOTE:** custom cable lengths available designated by /xx at the end of the part number; e.g. P1003V10AI/10 would have a 10m cable.

## INSTALLATION

The P100 should be wired as shown in the connections diagram on page 10.

Different P100 models have different connections, so make sure to use the correct diagram for your model.


Cable length can be extended to virtually any distance required. The proximity sensor is well protected against electrical interference, but if long cable runs are used in very noisy environments, the cabling should be segregated from any high current carrying and ideally shielded cables should be used for long-distance runs.

Blue LED (output) indicates target sensed.

### IMPORTANT:

The sensing face of the sensor, should overhang at least 20mm from any metalwork that the unit is fixed to, otherwise the unit will stay in the "ON" state. Ensure that any background metalwork, behind the target to be sensed, is at least 10mm behind the target. This will prevent the proximity sensor from detecting that background metalwork. Illustration A below denotes sensing ranges for ferrous and non-ferrous targets.





Ensure all connections are correct before applying power. Apply power to the P100 and machinery, then check that the output LED is flashing when the target is being sensed.



## WARNING

It is crucial that all exposed rotating shafts are provided with a full guard. Therefore, this device and its target must be equipped with a guard.

Fasten the P100 to a suitable mounting bracket, such as 4B's Whirligig® universal shaft sensor mount, with the nose of the switch within the sensing range of the target, as shown below -



## SPECIFIC CONDITIONS OF USE

1. The supply circuit shall be protected by a suitably rated fuse capable of interrupting a short circuit current of 1500 Amps.
2. Warning: Potential static ignition risk, clean only with a damp cloth. Warning: Potential static ignition risk, clean only with a damp cloth.
3. The integral cable shall be terminated in a suitably certified enclosure or in the safe area.
4. For Group I M2 applications the sensor shall only be used in areas with a low risk of impact.
5. For Group I M2 applications the sensor shall be protected from exposure to chemicals such as oils, greases and hydraulic liquids.

## STANDARD WIRING DIAGRAM




All wiring must be in accordance with local and national electrical codes and should be undertaken by an experienced and qualified electrician.

Where necessary, use dust/liquid tight flexible metal conduit with approved fittings to protect the sensor cables. Use rigid metal conduit to protect the cables from the sensors to the control unit. Conduit systems can channel water due to ingress and condensation directly to sensors and sensor connections which over time will adversely affect the performance of the system. As such, the installation of low point conduit drains is recommended for all sensors.

P1003V34AI (+V to Blue)




P1003V34AI (+V to Brown)




### WARNING

1500A capable fuse with 500mA maximum rating **MUST** be used for each sensor in order to comply with ATEX wiring regulations.


**Connections:**npn (E) energised output




**Connections:**npn (D) De-energised output



**Connections:**pnp (E) energised output



**Connections:**pnp (D) De-energised output



Note: NPN, Energised (top left) is the standard wiring to use this sensor with all the 4B controllers.

## TESTING AND COMMISSIONING

1. Check that the unit is correctly installed (see standard wiring diagram).
2. Check that the distance between the target, stud or bolt head and sensing face of P100 is within the minimum distance specified.
3. Start up machine.
4. If monitoring for speed see A, for proximity monitoring see B -
  - A. If the P100 is being used to monitor speed, 4B's *SpeedMaster*™ calibration and testing device can be used to insure the P100 shuts down the machine at the correct percentage of slip. Shut down will depend on your specific monitoring setup. 4B recommends an instant shutdown on any belts slipping 20% or more of normal speed.
  - B. If the P100 is being used as a proximity switch, be sure that the target is not within range of the sensor prior to testing. Use a metal putty knife or a small piece of metal and place it between the sensing face of the P100 and the target. This will cause the sensor to energize the output and the blue LED will turn ON. Removing the putty knife will de-energize the output and the LED will turn OFF.

### **WARNING**

If the system does not immediately shutdown as expected or alarm as required, then remove the machine from service until the problem has been diagnosed and corrected.

# TROUBLESHOOTING GUIDE

FAULT	REMEDY
LED Stays "ON"	<ul style="list-style-type: none"> <li>• Check that the sensing face of the sensor is not bolted directly to metalwork</li> </ul>
	<ul style="list-style-type: none"> <li>• Check that there is a space between the sensor face and any surrounding metalwork (20mm minimum)</li> </ul>
	<ul style="list-style-type: none"> <li>• Check that the machinery is rotating and that the target is actually leaving the sensor before reappearing</li> </ul>
	<ul style="list-style-type: none"> <li>• Check that background metalwork, behind target, is far enough away so as not to be detected</li> </ul>
LED Stays "OFF"	<ul style="list-style-type: none"> <li>• Check supply voltage to the sensor.</li> </ul>
	<ul style="list-style-type: none"> <li>• Check that target is within specified operating range of unit.</li> </ul>
	<ul style="list-style-type: none"> <li>• Check that machinery is rotating and that target is passing the sensing face of the sensor.</li> </ul>

# PRODUCT WARRANTY

## 1. EXCLUSIVE WRITTEN LIMITED WARRANTY

All products sold are warranted by the company 4B Components Limited, 4B Braime Components Limited, and 4B France herein after referred to as 4B to the original purchaser against defects in workmanship or materials under normal use for one (1) year after date of purchase from 4B. Any product determined by 4B at its sole discretion to be defective in material or workmanship and returned to a 4B branch or authorized service location, as 4B designates, shipping costs prepaid, will be, as the exclusive remedy, repaired or replaced at 4B's option.

## 2. DISCLAIMER OF IMPLIED WARRANTY

No warranty or affirmation of fact, expressed or implied, other than as set forth in the exclusive written limited warranty statement above is made or authorized by 4B. 4B specifically disclaims any liability for product defect claims that are due to product misuse, abuse or misapplications, as authorized by law, 4B specifically disclaims all warranties that the product is fit or merchantable for a particular purpose.

## 3. NO WARRANTY "BY SAMPLE OR EXAMPLE"


Although 4B has used reasonable efforts to accurately illustrate and describe the products in its catalogs, literature, and websites, such illustrations and descriptions are for the sole purpose of product identification and do not express or imply a warranty affirmation of fact, of any kind or a warranty or affirmation of fact that the products will conform to their respective illustrations or descriptions. 4B expressly disclaims any warranty or affirmation of fact, expressed or implied, other than as set forth in the exclusive written limited warranty statement above, including, without limitation, the implied warranties of merchantability and fitness for a particular purpose.

## 4. LIMITATION OF DAMAGES

Any liability for consequential, incidental, special, exemplary, or punitive damages, or for loss of profit whether direct or indirect, is expressly disclaimed.



With subsidiaries in North America, Europe, China, Asia, Africa and Australia along with a worldwide network of distributors, 4B can provide practical solutions for all your applications no matter the location.



#### **4B BRAIME COMPONENTS LTD.**

Hunslet Road  
Leeds  
LS10 1JZ  
United Kingdom  
Tel: +44 (0) 113 246 1800  
Fax: +44 (0) 113 243 5021

#### **4B DEUTSCHLAND**

9 Route de Corbie  
80800 Lamotte Warfusée  
France  
Tel: +49 (0) 700 2242 4091  
Fax: +49 (0) 700 2242 3733

#### **4B AFRICA**

14 Newport Business Park  
Mica Drive, Kya Sand  
2163 Johannesburg  
South Africa  
Tel: +27 (0) 11 708 6114  
Fax: +27 (0) 11 708 1654

#### **4B FRANCE**

35 Bis Rue Du 8 Mai 1945  
80800 Villers, Bretonneux  
France  
Tel: +33 (0) 3 22 42 32 26  
Email: 4b-france@go4b.com

#### **4B COMPONENTS LTD.**

625 Erie Avenue  
Morton, IL 61550  
USA  
Tel: 309-698-5611  
Fax: 309-698-5615

#### **4B ASIA PACIFIC**

Build No. 899/1 Moo 20  
Soi Chongsiri, Bangplee-Tam  
Ru Road, Tanbon Bangpleeyai,  
Amphur Bangplee,  
Samutprakarn 10540  
Thailand  
Tel: +66 (0) 2 173-4339  
Fax: +66 (0) 2 173-4338

#### **4B China**

F1, Building 5A,  
Jintong Industrial Park,  
8 West Lake Road,  
Wujin High & New TDZ,  
Changzhou, Jiangsu, PRC  
Tel: +86-519-88556006  
Email: 4b-china@go4b.com

#### **4B AUSTRALIA**

Building 1, 41 Bellrick Street  
Acacia Ridge  
Queensland 4110  
Australia  
Tel: +61 (0)7 3216 9365  
Fax: +61 (0)7 3219 5837



**www.go4b.com**